





STANDARD ARRIVAL CHART-INSTRUMENT


RJFF / FUKUOKA RNAV STAR RWY34

HAWKS EAST ARRIVAL / HAWKS WEST ARRIVAL / HAWKS NORTH ARRIVAL
HAWKS SOUTH ARRIVAL / ISKUP SOUTH ARRIVAL RNAV 1

Note 1) DME/DME/IRU or GNSS required.
2) RADAR service required.

<p>VAR 8° W</p> <p>1MIN(at or below FL140) 1.5MIN(above FL140)</p> <p>NOT TO SCALE</p>  <p>MHA 5000 MAX 230KIAS (at or below FL140) MAX 240KIAS (above FL140)</p>	<p>1MIN(at or below FL140) 1.5MIN(above FL140)</p>  <p>MHA 6000 MAX 230KIAS (at or below FL140) MAX 240KIAS (above FL140)</p>	<p>1MIN(at or below FL140) 1.5MIN(above FL140)</p>  <p>MHA 12000 MAX 230KIAS (at or below FL140) MAX 240KIAS (above FL140)</p>	<p>1MIN(at or below FL140) 1.5MIN(above FL140)</p>  <p>MHA 12000 MAX 230KIAS (at or below FL140) MAX 240KIAS (above FL140)</p>
---	--	--	---

1MIN(at or below FL140)
1.5MIN(above FL140)



MHA 5000
MAX 230KIAS (at or below FL140)
MAX 240KIAS (above FL140)

